

SERVICE BULLETIN

Number 20160708(2)

ABN: 55 051 202 067

Date 08/07/2016

Head Office

Unit 1/35 Rimfire Drive
Hallam, VIC 3803

Phone: 03 8786 3570

Fax: 07 5462 8396

sales@austwiderentals.com

Title: Replacement S/S handle for full length handle.

Models effected: ME-S6, ME-S7, ME-D10 and ME-T16.

Reasons:

1. Excess repetitive opening causes plastic handle to tear from frame.

Items Required:

1. Stainless Steel handle. Austwide Part No. 17375. Includes Self Drilling Screws.
2. Philips screw driver No.2
3. Cordless Drill.
4. 5 Minute Araldite.
5. Saw. Material to be cut is PVC.
6. Cleaning material

Method:

1. Use saw to remove handle portion from Door frame.
2. Remove plastic protection from S/S handle
3. Hold Handle in place (3mm from back edge of door frame)
4. Drill and attach handle. Note: top and bottom Screws drill into Aluminium corner Stakes. Centre crew drill into plastic
5. Remove Handle clean and apply Araldite.
6. Reattach handle



Use saw to cut off faulty handle



Replacement Handle Position approx. 3mm from back of frame



Handle Fitted